


TRAILER LIGHTING INTERFACE

Part No: **VTI**



The VTI senses vehicle lighting without loading the vehicle lighting circuits. It requires a separate power feed from the boot light feed or an ignition / auxiliary feed.

VTI Features

Protection:

- Prevents blown vehicle fuses and damage to the Vehicle Body Control Module from a short circuit in the trailer wiring.
- Enables the vehicle lighting to continue operating if there is a short or open circuit in the trailer wiring.
- Automatically recovers from a short circuit in the trailer wiring.
- Will carry a maximum load per circuit of 42 Watts.

Intelligent Monitoring:

- The VTI is compatible with trailers fitted with bulbs or LED lamps.
- The VTI will eliminate fault codes by prohibiting the trailer lamps from being detected by the vehicle electronics.

Installation Notes

The VTI is connected into the vehicle wiring harness as per the above diagram.